









EXIT Spare wheel

Assembly Instruction



Contact Information

EXIT Toys
P.O. Box 369, 7000 AJ Doetinchem
The Netherlands
MRO-23107-V01

Edisonstraat 83, 7006RB (NL)
Tel. : +31 314 796 020
Email : info@exittoys.com
Web : www.exittoys.com

www.exittoys.com